



ADB (BLACK) PBTv REMOTE FOR ADB SETTOPS - POWER, VOLUME & ADVANCED

CODE SEARCH METHOD

- PRESS and release the **TV** button
- PRESS and **HOLD** the **RCU SETUP** until the **TV** button blinks twice
- Enter in **9 9 1** and the **TV** button will blink twice
- Aim the remote at the **TV** and press and release the **POWER** button
- PRESS and **RELEASE** the **CH+** or **CH-** until the TV turns off
- PRESS the **POWER** button to turn the TV on
- PRESS the **RCU SETUP** button to store the code for the TV. The TV button will blink twice. The remote is now ready to operate the TV.

Volume (Use with Code Search Method)

- Press and release the **TV** button
- Press and hold the **SETUP** button until the TV button blinks TWICE
- Enter in **9 9 3**
- Press and release the **TV** button and wait until it blinks twice
- Once these steps have been completed, you should be able to control the volume +/- and the mute regardless of what "mode" you are in. (i.e. TV, STB)

THE LEARNING METHOD

Basically, this means that you can transfer the information from the FACTORY ISSUED remote to the ADB remote (power, volume, etc.) It bypasses having to do the code search method.

- Press the **RCU SETUP** until the last selected mode button blinks twice. (TV, DVD, etc.)
- Enter in **9 7 5**
- Press the **TV** button
- Press the button you wish to program (i.e. **POWER**) on the ADB remote
- Place the **ADB** remote and the **ORIGINAL** remote head-to-head about 2 inches apart.
- Press and **HOLD** the **SAME** button (power) on the **ORIGINAL** remote. The ADB remote TV button will blink rapidly and turn off. Keep holding the button on the **ORIGINAL** remote until the **TV** button on the ADB remote blinks twice.

**if the learning failed, the TV button will emit on long blink. You will have to repeat step 6.*